

SERVICE PART ORDERING CODES

| PART NUMBER | DESCRIPTION |
|-------------|---|
| P-077002 | Breather Adapter with O-ring |
| P-227533-01 | Bleed plug and seal (Δ P port) |
| P-426225-01 | Bracket for W610 housing |
| P-426218-01 | Bracket for W620 housing |
| P-227567-01 | Element Connector for stacking E405 elements |
| P-236995-01 | Bracket for W041 housing |
| P-232964-01 | Welding Ring for WL16 Series intank filter |
| P-226195-01 | Dust Cover for Visual Δ P Indicator |
| P-232965-01 | Pressure Gauge for 25 psid bypass WL16/18, WT15, W021, W012, W015, WR11, WR15, WR17, W022 |
| P-238114-01 | Pressure Gauge for 50 psid bypass W015, W022, W021 & WL16/18 |
| P-233051-01 | Electrical Switch for WL16, WT15, W012, W015, WR11, WR15, WR17, W021, and W022 series filters with DIN connector, 18 PSI |
| P-233573-01 | Electrical switch for WL16/18, W015, W021, and W022 Series filters with DIN connector, 35 PSI |
| P-234117-01 | Electrical Switch for WL16/18, WT15, W021, W012, W015, WR11, WR15, WR17, and W022 Series filters with Brad Harrison connector, 18 PSI |
| P-234118-01 | Electrical Switch for WL16/18, W015, W021 and W022 Series filters with Brad Harrison connector, 35 PSI |
| P-233637 | Weld Ring for WT15 housing |
| P-234882 | Cover Assembly for WT15 housing |
| P-134230 | Cover Assembly for WL16 housing |
| P-235098 | 25 PSID Bypass Assembly for WL16 |
| P-234728 | 50 PSID Bypass Assembly for WL16 |
| P-334277 | Testing block assembly for indicators |
| P-235419-01 | Cap Sub-Assembly (Buna N) W451 |
| P-235419-03 | Cap Sub-Assembly (Viton) W451 |
| P-40005 | Hold Down Spring WL16 |
| P-236927 | Weld Ring for WR11 housing |
| P-236929 | Weld Ring for WR15 housing |
| P-236930 | Weld Ring for WR17 housing |
| P-137547 | Check Valve for WL16 bowl |
| P-238962 | 25 psid bypass assembly for WL18 |
| P-234699-01 | Buna N grommet for E405 elements |
| P-234699-03 | Viton grommet for E405 elements |
| P-239290 | WL16 Diffuser |
| P-239291 | WL18 Diffuser |